

## AT-HDCAT Updating Guide

New firmware to update, fix, or change functionality of products becomes available occasionally. Atlona has made this as easy as possible for updating on the job by simply downloading from Atlona.com and installing through a USB A to USB B cable.

**NOTE:** Only use a Windows computer to update. Use of an Apple computer to update will cause the device to be unusable until a Windows computer is used to update.

### I. Requirements:

- a. AT-HDCAT w/ power supply
- b. Desktop PC or Laptop PC w/ USB B port
- c. USB A to USB B cable

### II. Installation:

- a. Connect AT-HDCAT and PC by using a USB A to USB B cable.

### III. Enter Update Mode:


- a. Unplug the power supply from AT-HDCAT if it is plugged in.
- b. Press and HOLD the EDID button.
- c. Plug in the power supply.

### IV. Firmware Upgrade:

- a. Click the option, "Open folder to view files".



If the computer does not auto detect the connection, open "My Computer" and select the USB drive.



- b. Delete any files in the folder. (There should be only 1)
- c. Copy and paste the new firmware into the folder
- d. Disconnect the USB cable from the HDCAT and computer
- e. Unplug the power cable from the HDCAT
- f. Plug the power cable back and turn the matrix on

The update should be complete