

Update Instructions


Requirements:

- AT-OME-EX-TX-LT
- AT-OME-EX-RX-LT
- Firmware file
- Computer running Windows
- USB-A to micro-USB cable



IMPORTANT: The AT-OME-EX-KIT-LT should be updated as a kit, and the TX and RX should be connected via their HDBaseT connectors prior to the firmware update.

1. Disconnect power from the AT-OME-EX-RX-LT.
2. Make sure the AT-OME-EX-TX-LT and AT-OME-EX-RX-LT are connected to the **HDBaseT** ports using a category (CAT-5e or better) cable.
3. Connect a USB-A to micro-USB cable between the PC and the **FW** port on the AT-OME-EX-TX-LT (transmitter).
4. Power the AT-OME-EX-RX-LT.
5. The USB UPDATE folder will be displayed. If this folder is not displayed, automatically, select the USB UPDATE drive from Windows Explorer.
6. Delete all files from the USB UPDATE drive, if any are present.



7. Drag-and-drop the firmware file to the drive.
8. The **PWR** LED indicator, on the front panel, will flash green while the unit is being updated. Do not disconnect the USB cable during the update process. When the **PWR** LED stops flashing and is solid green, the update process will be complete.