

Update Instructions


Requirements:

- AT-OME-EX-TX-WPC
- Firmware file
- Computer running Windows
- Micro-USB to USB-A cable




IMPORTANT: Do not disconnect power from unit during the firmware update process. Doing so may damage the unit.

1. Disconnect power from the AT-OME-EX-TX-WPC, which can be done by disconnecting the category cable from the HDBaseT port on the receiver.
2. Remove the faceplate to access the hidden “firmware update” button, located above the PWR LED indicator.



3. Connect a micro-USB to USB-A cable from the micro-USB port on the AT-OME-EX-TX-WPC to a PC.
4. Simultaneously press and hold the firmware update button, while reconnecting the power. The **PWR** LED indicator will be blinking green.
5. The USB UPDATE folder will be displayed. If this folder is not displayed, automatically, select the USB UPDATE drive from Windows Explorer.



Update Instructions

6. Drag and drop the firmware file into the USB drive folder.
7. After the firmware file has been placed in the folder, the firmware update process will begin. During the update process, the **PWR** LED indicator will flash green.
8. Once the update process is complete, the AT-OME-EX-TX-WPC will automatically reboot.
9. Once the **PWR** LED returns to solid green, the firmware update process is complete. The firmware update process takes approximately 10 to 15 seconds to complete.