

AT-HDVS Updating Guide

New firmware to update, fix, or change functionality of products becomes available occasionally. Atlona has made this as easy as possible for updating on the job by simply downloading from Atlona.com and installing through a mini USB to USB A cable.

NOTE: Only use a Windows computer to update. Use of an Apple computer to update will cause the device to be unusable until a Windows computer is used to update.

I. Requirements:


- a. AT-HDVS-RX
- b. Desktop PC or Laptop PC
- c. Mini USB to USB A cable

II. Installation:


- a. Disconnect the power from the AT-HDVS-RX.
- b. Connect AT-HDVS-RX and PC (with mini USB to USB A cable) while holding the menu button on the HDVS-RX.

III. Firmware Upgrade:

- a. Click the option, "Open folder to view files".



If the computer does not auto detect the connection, open "My Computer" and select the USB drive.



- b. Delete any files in the folder. (There should be only 1)
- c. Copy and paste the new firmware into the folder
- d. Disconnect the USB cable from the HDVS and computer
- e. Plug the power cable into the HDVS

The update should be complete

Note: For full functionality and features, ensure the transmitter and receiver are using compatible firmware

	Receiver firmware V 1.0.1	Receiver firmware V 1.1.0	Receiver firmware V 2.0.0
Transmitter firmware V 1.0.1	Compatible	Not Compatible	Not Compatible
Transmitter firmware V 1.1.0	Not Compatible	Compatible	Compatible
Transmitter firmware V 2.0.0	Not Compatible	Compatible	Compatible
GUI Version	1.4	1.1.0	1.1.0