



## Update Instructions

Firmware for the AT-RON-444 is updated through the mini-USB port on the rear panel.

Requirements:

- New firmware - Downloaded from [atlona.com](http://atlona.com)
  - Computer running Windows.
  - USB-A to mini-B USB cable.
1. Disconnect power from the unit.
  2. Press and hold the **EDID** button.
  3. Connect a mini-USB type-B to USB type-A type cable from the **FW** port on the AT-RON-444 to a USB port on the computer contains the firmware file.
  4. Press and hold the **EDID** button while reconnecting power to the unit.
  5. The internal disk folder for the AT-RON-444 will be displayed. If the AutoPlay dialog is displayed, then click the "Open folder to view files" option.



6. Remove any existing firmware files from the drive.
7. Drag and drop the firmware file on to the drive.
8. During the firmware update, the LED indicators on the front panel will blink. Do not disconnect the USB cable during the update process. Once the LED indicators stop blinking, the firmware update process will be complete.
9. Disconnect the USB cable from the AT-RON-444, and reconnect the power supply.