

Update Instructions

Requirements:

- AT-UHD-EX-70C-TX
- AT-OPUS-RX
- Computer with firmware file
- USB-A to USB mini-B cable

1. Connect a USB to mini-USB cable from the FW port on the unit to an available USB port on the computer.



NOTE: The AT-UHD-EX Series can be powered over USB during the firmware update procedure. Therefore, connection of an external power supply (or HDBaseT) is not required.

2. Identify the correct batch (.bat) script for the product that is being updated, from the table below. Note that there are separate scripts for both TX and RX units.

| Valens (VS010) | |
|-----------------------------|--|
| UpdateVS010RX_[version].bat | AT-UHD-EX-70-2PS (RX) AT-UHD-EX-70-RX AT-UHD-EX-70C-RX |
| UpdateVS010TX_[version].bat | AT-UHD-EX-70-2PS (TX) AT-UHD-EX-70-TX AT-UHD-EX-70C-TX |
| Valens (VS100) | |
| UpdateVS100RX_[version].bat | AT-UHD-EX-100-CE-RX AT-UHD-EX-100CE-RX-PSE |
| UpdateVS100TX_[version].bat | AT-UHD-EX-100CE-TX AT-UHD-EX-100CE-TX-PD |

3. Double-click the batch file to execute it.



IMPORTANT: Do not disconnect the USB cable during the update process.

4. After the update procedure is complete, the software will go through the verification process and then display the following message:

Verification succeeded!!! :-)