



OMEGA™

4K / UHD

**Two-Input EU/UK Wallplate Switcher
for HDMI and USB-C with HDBaseT™ Output**

Application Programming Interface
1.0.22

Version Information

Version	Release Date	Notes
1	Dec 2018	Initial release
2	Feb 2020	Firmware 1.0.22; refer to the release notes for a full list of features and bug fixes. - Hostname information is now returned with the System sta command. - Added DispBtn command.

Introduction

General

This document provides an alphabetical list of commands available for AT-OME-TX21-WP-E. Commands are case-sensitive. If the command fails or is entered incorrectly, then the feedback is “Command FAILED”. Commands can be sent using RS-232, Telnet, SSH, or TCP. There should be a 500 millisecond delay between each command sent to the unit. The default port for Telnet is 23. TCP ports are 9000 and 9001.



IMPORTANT: Each command is terminated with a carriage-return (0x0d) and the feedback is terminated with a carriage-return and line-feed (0x0a).

Ports

This product can communicate directly with local and remote RS-232 (over HDBaseT) ports using a direct TCP socket connection. The default port assignment is from left-to-right, viewed from the rear panel. Refer to the table below for the port assignment for this product. For ports connected to RS-232 interfaces, no additional payload is required to transmit data to the device. All data sent to the respective TCP port will be sent bit-for-bit to the RS-232 output. Note that if feedback is required from the RS-232 device, the TCP socket must be kept open. This product does not provide buffer or queuing registers. Therefore, any data from the RS-232 port that is received while the TCP socket connection is closed, will be lost.

Port	Description
9000	MCU (similar to Telnet)
9001	HDBaseT RS-232 port
9002	Local RS-232 port

Example:

With the device IP address of 192.168.1.100 and a PJLINK projector connected to the RS-232 of the HDBaseT output.

1. Open a TCP socket to 192.168.1.100:9001 and send the following command string:

```
%1POWR 1\x0D
```

2. The projector will respond with the following, using the same socket connection:

```
$1POWR=OK\x0D
```

Commands

Command	Description
CommaWait	Enables or disables a five second delay when using commas in the command line
DispBtn	Simulates pressing the DISPLAY button on the front panel
Display	Powers-on or power-off the connected display
HDMIAud	Enables or disables audio output
help	Displays a list of available help commands
InputStatus	Displays the status for each input
IPCFG	Displays IP address configuration
IPDHCP	Turns DHCP on / off
IPStatic	Sets a static IP address
Lock	Locks the buttons on the front panel
Mreset	Sets the unit back to default settings
PWOFF	Execute this command to power-off the unit
PWON	Execute this command to power-on the unit
RepCmdTime	Sets the number of times a command is repeated
RepeatCmd	Enables or disabled the RepCmdTime feature
RS232zone	Triggers the unit to send the RS-232 command to the display connected to the HDBaseT receiver's RS-232 port
Status	Displays the routing state of the unit
System	
Type	Displays the model of the unit
Unlock	Unlocks the buttons on the front panel
Version	Displays the current firmware version of the unit
xYAVxZ	Switches the specified input to the specified output

CommaWait

The comma is frequently used to separate multiple commands on the command line. However, the client may require time to execute a specific command, before the next command is executed. Enabling this command will assign a five second delay to any comma delimiters, found within the command line.

Syntax

```
CommaWait X
```

Parameter	Description	Range
X	State	on, off, sta

Example

CommaWait on

Feedback

CommaWait on

DispBtn

This command emulates pressing the **DISPLAY** button on the front panel. This command can perform different functions, depending on which value it is assigned.

Syntax

```
DispBtn X
```

Parameter	Description	Range
X	State	on, off, tog, sta

Example

DispBtn on

Feedback

DispBtn on

Display

This command powers-on or powers-off the connected display.

Syntax

```
Display X
```

Parameter	Description	Range
X	State	on, off, sta

Example

Display on

Feedback

Display on

HDMI Aud

Enables or disables the audio output on the HDMI port. on = enables HDMI audio output; off = disables HDMI audio output. Use the sta argument to return the current HDMI audio output state

Syntax

```
HDMI Aud
```

Parameter	Description	Range
X	State	on, off, sta

Example

```
HDMI Aud off
```

Feedback

```
HDMI Aud off
```

help

Displays the list of available commands. To obtain help on a specific command, enter the **help** command followed by the name of the command.

Syntax

```
help [X]
```

Parameter	Description	Range
X	Command name (optional)	Command

Example

```
help
```

Feedback

```
CommaWait
DispBtn
System
IPCFG
IPStatic
...
...
...
```

InputStatus

Displays the status of the inputs as either a 0 or 1. If a source is detected on the input, then a 1 will be displayed. Inputs with no source connected will display a 0.

Syntax

```
InputStatus
```

This command does not require any parameters

Example

```
InputStatus
```

Feedback

```
InputStatus 01
```

IPCFG

Displays the current network settings for the unit.

Syntax

```
IPCFG
```

This command does not require any parameters

Example

```
IPCFG
```

Feedback

```
IP Addr: 10.0.1.101
Netmask: 255.255.255.0
Gateway: 10.0.1.1
Telnet Port: 23
```

IPDHCP

Enables or disables DHCP mode on the unit. on = enables DHCP mode; off = disables DHCP mode; sta = displays the current setting. If this feature is disabled, then a static IP address must be specified for the unit. Refer to the [IPStatic](#) command for more information.

Syntax

```
IPDHCP X
```

Parameter	Description	Range
X	Value	on, off, sta

Example

```
IPDHCP on
```

Feedback

```
IPDHCP on
```

IPStatic

Sets the static IP address, subnet mask, and gateway (router) address of the unit. Before using this command, DHCP must be disabled on the unit. Refer to the **IPDHCP** command for more information. Each argument must be entered in dot-decimal notation and separated by a space. The default static IP address is 192.168.1.254.

Syntax

```
IPStatic X Y Z
```

Parameter	Description	Range
X	IP address	0 ... 255 (per byte)
Y	Subnet mask	0 ... 255 (per byte)
Z	Gateway (router)	0 ... 255 (per byte)

Example

```
IPStatic 192.168.1.112 255.255.255.0 192.168.1.1
```

Feedback

```
IPStatic 192.168.1.112 255.255.255.0 192.168.1.1
```

Lock

Locks the buttons on the front panel. This feature is useful when the unit is installed in a rack environment or other remote location, to prevent unauthorized tampering or accidental pressing of the front-panel buttons. Also refer to the **Unlock** command.

Syntax

```
Lock
```

This command does not require any parameters

Example

```
Lock
```

Feedback

```
Lock
```

Mreset

Resets the unit to factory-default settings.

Syntax

```
Mreset
```

This command does not require any parameters

Example

```
Mreset
```

Feedback

```
Mreset
```


PWOFF

Executing this command will power-off the unit. Execute the **PWON** command to power-on the unit.

Syntax

```
PWOFF
```

This command does not require any parameters

Example

```
PWOFF
```

Feedback

```
PWOFF
```

PWON

Executing this command will power-on the unit. Use the **PWOFF** command to power-off the unit.

Syntax

```
PWON
```

This command does not require any parameters

Example

```
PWON
```

Feedback

```
PWON
```

RepCmdTime

Sets the number of time a command will be sent. This may be required in systems where a command must be transmitted more than once, before an acknowledgement message is received. Specify the sta argument to display the current setting.

Syntax

```
RepCmdTime X
```

Parameter	Description	Range
X	Times to repeat command	2 ... 4, sta

Example

```
RepCmdTime 3
```

Feedback

```
RepCmdTime 3
```

RepeatCmd

Enables / disables the `RepCmdTime` feature. Specify the `sta` argument to display the current setting.

Syntax

```
RepeatCmd X
```

Parameter	Description	Range
X	State	on, off, sta

Example

```
RepeatCmd on
```

Feedback

```
RepeatCmd on
```

RS232zone

Sends commands to the HDBaseT device. Refer to the User Manual of the display device for a list of available commands. Brackets must be used when specifying the command argument. The command line must not contain any spaces. Since the AT-OME-TX21-WP-E has only one HDBaseT output (zone), "1" must be specified as the first argument. Note that this command is deprecated and for legacy use. It is recommended to use the TCP socket functionality mentioned above.

Syntax

```
RS232zone[X]
```

Parameter	Description	Range
X	Command	String

Example

```
RS232zone1[test]
```

Feedback

```
RS232zone1[test]
```

Status

Displays which input is routed to which output. Refer to the `xYAVxZ` command for more information.

Syntax

```
Status
```

This command does not require any parameters

Example

```
Status
```

Feedback

```
x1AVx1
```

System

Displays information about the AT-OME-TX21-WP-E. The sta argument must be specified.

Syntax

```
System X
```

Parameter	Description	Range
X	Constant	sta

Example

```
System sta
```

Feedback

```
Model: AT-OME-TX21-WP-E
MAC Addr: b8:98:b0:00:01:53
Address Type: DHCP
IP Addr: 10.20.40.117
Netmask: 255.255.255.0
Gateway: 10.20.40.1
Http Port: 80
Telnet Port: 23
Firmware: 1.0.22
On/Up Time <dd HH:mm:ss>: 0 20:58:4
Hostname: OMETX21-000153
```

Type

Displays the model information of the unit.

Syntax

```
Type
```

This command does not require any parameters

Example

```
Type
```

Feedback

```
AT-OME-TX21-WP-E
```

Unlock

Unlocks the buttons on the front panel. Also refer to the [Lock](#) command.

Syntax

```
Unlock
```

This command does not require any parameters

Example

```
Unlock
```

Feedback

```
Unlock
```

Version

Displays the current firmware version of the unit.

Syntax

```
Version X
```

Parameter	Description	Range
X	Chip	mcu, vstx, vsrx

Example

```
Version MCU
```

Feedback

```
1.0.22
```

xYAVxZ

Switches the specified input to the specified output. The first argument references the input: 1 = HDMI, 2 = USB-C.

Syntax

```
xYAVxZ
```

Parameter	Description	Range
Y	Input	1, 2
Z	Output	1

Example

```
x1AVx1
```

Feedback

```
x1AVx1
```

