

# Update Instructions


## Requirements:

- AT-UHD-SW-5000ED
- Firmware file
- Computer on a network that can reach the network where AT-UHD-SW-500ED is connected



**IMPORTANT:** Updating the firmware will require physical access to the device. Please ensure access prior to updating the firmware.

1. Download the latest firmware from [atlona.com](http://atlona.com) and extract the contents of the .zip file to a folder on the computer.
2. Connect the computer, containing the firmware files, to the same network as the AT-UHD-SW-5000ED.
3. Press and release the **IP** button on the front panel. The IP address of the AT-UHD-SW-5000ED will appear on the connected display.
4. Launch a web browser and enter the IP address of the AT-UHD-SW-5000ED in the address bar.
5. The **Login** screen will be displayed. Enter the login credentials.
6. Click **Update** in the top menu bar.
7. Click **Choose File** under the **Firmware Update** section and select the `AT_UHDSW_5000ED_[version].BIN` firmware file.
8. Click the **Upload** button.



The screenshot shows the web interface of the AT-UHD-SW-5000ED device. At the top is a navigation bar with links: Home, Network Setup, Settings, Config, EDID, Control, and Update. The 'Update' link is highlighted. Below the navigation bar, there are two main sections: 'Firmware Update' and 'Valens Update'. Each section contains a 'Choose File' button, a text field showing 'No file chosen', an 'Upload' button, and a progress bar. The progress bars for both sections are currently at 0%.

9. Wait for the screen to turn white.
10. Disconnect power from the AT-UHD-SW-5000ED, then reconnect power.
11. The Top Volume LED on the front panel will turn red to show FW update in progress.
12. Wait for the VOLUME LED to turn back on.
13. Login to the AT-UHD-SW-5000ED.